


L8543337
05/2022 rev 6

ARIA ARIA S

Installation and maintenance manual for swing doors



1. Preliminary information 1.1 General safety warnings 1.2 CE marking and European Directives	page 3
2. Technical data 2.1 Instructions for use 2.2 Identification of parts	page 4
3. Type of installation	page 5
4. Wall mounting procedure	page 6
5. Procedure for ARIA installation with sliding arm inwards 5.1 AIR fixing with sliding pulling arm (01FE0056)	page 7
6. ARIA installation procedure with outward sliding arm 6.1 ARIA fixing with pushing sliding arm (01FE0060)	page 8
7. ARIA installation procedure on the lintel on the hinge side 7.1 ARIA fixing with elbow arm (01FE0057/01FE0058)	page 9
8. ARIA installation procedure with articulated arm to open door outwards 8.1 ARIA fixing with articulated arm (01FE0055)	pag.10.
9. Adjustments and settings with spring 9.1 "BRAKE.S" electronic control board	pag.11.
10. Electrical connections 10.1 General electrical safety warnings 10.2 Electrical power supply connection 10.3 Electronic control terminal boards 10.4 Electrical connections of the functions selector 31SR0011 - 31SR0012 10.6 Electrical connections of the opening and safety sensors 10.7 Electrical connections of the safety sensors (articulated arm for opening inwards)	page 12
11. Low Energy Adjustment	page 16
12. Menu 12.1 Menu List 12.2 BASE menu 12.3 INFO menu 12.4. MEM menu 12.5 ADV menu 12.6 SEL menu	page 17
13. Warnings 13.1 Alarms 13.2 Events	Page 22
14. Functional instructions for synchronised and interlocked automations 14.1 Introduction 14.2 Connection wiring 14.3 Synchronisation of two automations 14.4. Interlock of two automations	page 23
15. Start-up procedure for automatic swing door	page 25
16. Troubleshooting	page 26
17. Routine maintenance plan for automatic swing door	page 27
Maintenance log book	page 28
Declaration of Incorporation	page 32
Instructions for use	page 33

Dear Customer, In thanking you for your preference, we recommend that you carefully read the following instructions for installation and use of the automation, in order to obtain the optimal performance. We also remind you that assembly of this product must only be carried out by professionals.

Before starting installation or activating an automatic wicket, an inspection must be carried out on site by professionally competent staff, to take the measures of the wall compartment, the fixture and the automation.

This inspection is necessary to assess the risks and to choose and apply the most appropriate solutions based on the type of pedestrian traffic (heavy, limited, one-directional, two-directional, etc.), the type of users (elderly, disabled, children, etc.) and the presence of potential hazards or particular local situations.

1.1 GENERAL SAFETY WARNINGS

This assembly, installation and maintenance manual is exclusively for professionally competent staff. Read the instructions carefully before starting to install the product.

Wrong installation can be a source of danger. The packaging materials (plastic, polystyrene, etc.) should not be disposed of in the environment and must not be left within children's reach since they are potential sources of danger. Before starting installation, check the product is intact. Do not install the product in an explosive environment and atmosphere: the presence of flammable gas or fumes poses a serious danger for health.

Before installing the automation, make all the structural changes relating to the construction of the safety clearance and the protection or segregation of all the crushing, shearing, conveying and danger zones in general.

Check the existing structure has the necessary robustness and stability requirements. MYONE S.r.l. cannot be held responsible for any non-compliance with good practice in the construction of fixtures to automate, as well as deformations which occur during use. The safety devices (presence sensors, photocells, etc.) must be installed while taking into consideration: the standards and directives in force, good practice techniques, the installation environment, the operating logic of the system and the forces developed by the automatic wicket.

Apply the signs planned by the standards in force to identify the danger zones. Each installation must have visible indication of the identification data of the automatic wicket gate.

1.2 CE MARKING AND EUROPEAN DIRECTIVES



MYONE automations for pedestrian sliding doors are designed and built in compliance with the safety requirements of the European standard EN 16005 and are equipped with CE marking in compliance with the Electromagnetic Compatibility Directive (2014/30/EU). MYONE automations are equipped with a Declaration of Incorporation for the Machinery Directive (2006/42/EC).

Pursuant to the Machinery Directive (2006/42/EC) the installation technician implementing the automatic wicket has the same obligations as the manufacturer of the machine and, as such, must:

- prepare the technical file which must contain the documents indicated in Annex V of the Machinery Directive;
(The technical file must be kept and maintained available to the competent national authorities for at least ten years starting from the date of automatic wicket manufacture);
- draft the EC Declaration of Conformity according to Annex II-A of the Machinery Directive and deliver it to the customer;
- affix the CE marking on the automatic wicket pursuant to point 1.7.3 of Annex I of the Machinery Directive.

The data shown in this manual have been prepared and checked with the utmost care.

However, MYONE S.r.l. cannot be held in any way liable for possible errors, omissions or approximations due to technical or graphical requirements.

MYONE S.r.l. reserves the right to make changes to improve products. For this reason, the illustrations and information that appear in this document should be considered non-binding.


This edition of the manual deletes and replaces previous ones. If changes are made, a new edition will be issued.

Complying with the working temperature range declared in the technical data would allow you to obtain the use frequency value in the table.


The data are detected in the standard use conditions and cannot be guaranteed for each individual case.

Each automatic input has variable elements, such as: friction, balancing, environmental conditions which can substantially change both the working duration and quality of the automatic input or part of its components.

The installation technician is responsible for implementing the adequate safety coefficients for each particular situation.


Technical data	ARIA	ARIA S
Compress.	Automatic swing door for pedestrian passages	
Power supply	Full range 100-240 Vac 50/60 Hz	
Operating type	motor opening / motor closure	motor opening / spring closure
Opening time	3÷12 s / 90°	5÷15 s / 90°
Closing time	5÷12 s / 90°	6÷15 s / 90°
Maximum torque	45 Nm	28 Nm (opening) 18 Nm (closure)
Consumption in stand-by	3 W	3 W
Total consumption	70 W	
Accessories power supply	24 Vdc 1 A max	
Operating temperature		
Protection rating	IP 31	
Type and frequency of use	Continuous operation = 100%	
Weight	8.5 Kg	9.5 Kg


2.1 INSTRUCTIONS FOR USE



2.2 IDENTIFICATION OF PARTS

1. Command control unit CP.ARIA
2. Gearmotor 24Vdc with encoder
3. Spring unit (ARIA S)
4. Reducer unit
5. Power supply
6. Side head
7. Aluminium frame
8. Arm attachment bushing
9. Oxidised aluminium casing
10. Emergency Battery KIT (OPTIONAL)






Ref.	Code	Description
1	ARIA	ARIA automation for hinged doors
	ARIA S	ARIA S spring automation S for hinged doors
2	01FE0056.	Pulling sliding arm
	01FE0060.	Sliding pushing arm
	01FE0057 / 01FE58	Elbow Sliding Arm
	01FE0055.	Articulated arm
3	31RS0001.	Safety sensor
	31RS0002.	
3a	31RS0006.	Safety sensor
	31RS0007.	
	31RS0008.	
4	31RM0002.	Opening sensor
	31RM0003.	
	31RM0004.	
5	31SR0011.	Rotary selector for external cable hinges
	31SR0012.	Rotary selector for external cable hinges with key

PLEASE NOTE: The components and codes indicated are those most used in systems for automatic swing doors. However, the complete range of devices and accessories is available on the sales pricelist.




For system installation, use accessories and safety devices approved by MYONE S.r.l.

- 1 - Check the wall is straight and smooth.
- 2 - Drill using the template provided, or in any case respecting the measurements as shown in Fig. A.
- 3 - Insert the plugs or thread, depending on the material of which the wall is made.
- 4 - Fix well the automation to the wall by tightening the screws.

Fig. A






5.1 ARIA FASTENING WITH SLIDING PULLING ARM (01FE0056)





If necessary, use extension 01FE0054 to increase the distance between the automation and the guide.

Fix the sliding guide on the door as shown in the figures, respecting the measures indicated and cutting the excess part of the guide if the door is tight.


Adjust the opening end stop inside the guide, as indicated in the figure.



6.1 AIR FASTENING WITH PUSHING SLIDING ARM (01FE0060)



$X^* = \max 13\text{mm}$ (STANDARD)





$X^* = \max 68\text{mm}$ (STANDARD+01FE0054)

If necessary, use extension 01FE0054 to increase the distance between the automation and the guide.

Fix the sliding guide on the door as shown in the figures, respecting the measures indicated and cutting the excess part of the guide if the door is tight.



Adjust the opening end stop inside the guide, as indicated in the figure.




Manually move the opening and closing door checking there is no friction.

The maximum opening angle depends on the wall thickness:

7.1 ARIA FIXING WITH ELBOW ARM (01FE0057/01FE0058)



$X^* = 10\text{mm}$ (STANDARD)





$X^* = 65\text{mm}$ (STANDARD+01FE0054)

If necessary, use extension 01FE0054 to increase the distance between the automation and the guide.



Fix the sliding guide on the door as shown in the figures, respecting the measures indicated and cutting the excess part of the guide if the door is tight.

Adjust the opening end stop inside the guide, as indicated in the figure.




Z	Y
120	150 (01FE0057)
220	250 (01FE0058)

8.1 ARIA FIXING WITH ARTICULATED ARM (01FE0055)



$X^* = \max 13\text{mm}$ (STANDARD)



$X^* = \max 68\text{mm}$ (STANDARD+01FE0054)



If necessary, use extension 01FE0054 to increase the distance between the automation and the guide.

Drill the door and fix the articulated arm in accordance with the measurements shown in the figures.

Install a mechanical stop for the open door on the floor or ceiling (not supplied by us).


ATTENTION:

The floor-mounted door stops must be fixed in a visible position and must not constitute a tripping hazard.



Change length of articulated arm:

- 1 - Unscrew the 4 M5 screws
- 2 - Stretch/shorten the rod (+/-)
- 3 - Tighten the 4 M5 screws



Depending on the installation on the right or left, use the cam part that allows the correct spring closure.

Adjust the thrust in the lock due to the spring by acting on the nut A and set the desired preload in the lock by acting on the position of the arm.



BRAKE S electronic board adjustments and tests must be performed before starting the system.

Manually move the door to check a fluid movement in opening and slowed down in closing.


The BRAKE S electronic board is designed to allow the slow closing of non-powered automatisations (e.g. without mains power).

PLEASE NOTE: The preloading of the springs gives a slight push on the door even after the complete closure.

9.1 "BRAKE.S" ELECTRONIC CONTROL BOARD



1	JUMPER IN SLIDING PULL OR ELBOW ARM POSITION (CODE 01FE0056/01FE0057/01FE0058) OPEN TO THE RIGHT JUMPER IN ARTICULATED OR SLIDING PUSH ARM POSITION (CODE 01FE0055/01FE0060) OPEN TO THE LEFT
2	JUMPER IN SLIDING PULL OR ELBOW ARM POSITION (CODE 01FE0056/01FE0057/01FE0058) OPEN TO THE LEFT JUMPER IN ARTICULATED OR SLIDING PUSH ARM POSITION (CODE 01FE0055/01FE0060) OPEN TO THE RIGHT
A	JUMPER POSITIONED FOR MAXIMUM BRAKING IN CLOSED
B	JUMPER POSITIONED FOR MINIMUM BRAKING IN CLOSED



Ref.	Terminals	Description
1	PWR	Mains power supply board
2		CP.ARIA electronic control
3	MOT	Direct current gearmotor
	ENC	Angular sensor
4	BAT	99BA0004 KIT (optional)
5	LK	Electric lock
6		31IB0001 operating mode selector

10.1 GENERAL ELECTRICAL SAFETY WARNINGS

The installation, electrical connections and adjustments must be carried out in compliance with good practice and in compliance with standards in force.

Before connecting the electrical power supply, ensure the plate data correspond to those of the electrical distribution mains. On the power supply mains, install an omnipolar switch/sectioning device with an opening distance of the contacts equal or over 3mm. This switch must be protected from unauthorised activations.

Check upstream of the electrical system that there is an adequate differential switch and an overcurrent safety device.

Connect the automation to an efficient earthing system installed as indicated by safety standards in force.

During installation, maintenance and repair operations, remove the power supply before opening the casing to switch on the electrical parts.

The electronic parts must be handled using anti-static, conductive wrist straps connected to the ground.

MYONE S.r.l. cannot be held in any way liable if components are installed which are incompatible for safety purposes and for good operation.

For possible repair or replacement of products, only original spare parts must be used.

The plate data are found on the label positioned in front.

10.2 ELECTRICAL POWER SUPPLY CONNECTION

The connection to the mains can be made, using a suitable power cable (not of our supply) as follows:


a. passing from the base of the automation using the appropriate slots, when a wall channel has been prepared (independent and separate from the connections to the control and safety devices)

PLEASE NOTE: Make sure there are no sharp edges that could damage the power cord.

b. Through the automation head, when the path of the power cable is external to the automation fixing wall, drilling the head and using a cable press (not of our supply). Connect the cable to a junction box, or to the wall socket via an electrical plug (not of our supply).

10.3 ELECTRONIC CONTROL TERMINAL BOARDS

When you connect the safety devices, remove the jumpers of the corresponding terminals.









Terminals J20 (grey)	Description
L / H / +24V / -24 V	BUS connection to the electronic function selector/programmer and/or for door synchronisation/interlocking
Terminal J3 (green)	Description
TS	Test output: Connect the safety devices with testing (compliance with standard EN 16005), as indicated in the following chapters. PLEASE NOTE: For devices without testing, connect the N.C. contact to the TS/OS terminals.
+24V / OS	Safety N.C. contact opening. When the door is opening, opening the contact causes the door to stop in the last 0+50°(the safety function of the OS terminal can be changed using the advanced parameters menu). PLEASE NOTE: Connect the safety devices with testing (see TS terminal) and remove the TS/OS jumper.
+24V / -24V	24 Vdc output for external accessories supply. Maximum absorption of 1 A corresponding to the sum of all the terminals (+/- 24V).
Terminals J10 (black)	Description
TS	Test output. Connect the safety devices with testing (compliance with standard EN 16005), as indicated in the following chapters. PLEASE NOTE: For devices without testing, connect the N.C. contact to the TS/CS terminals.
+24V / CS	Safety N.C. contact closing (left side automation view). When the door is closing, opening the contact causes the door to reverse in the last 500 mm (the safety function of the CS terminal can be changed using the advanced parameters menu). PLEASE NOTE: Connect the safety devices with testing (see TS terminal) and remove the TS/CS jumper.
+24V / -24V	24 Vdc output for external accessories supply. Maximum absorption of 1 A corresponding to the sum of all the terminals (+/- 24V).
J5 clamp (grey)	Description
+24V/OP-E	N.O. contact opening side B (external side automation view).
+24V / -24V	24 Vdc output for external accessories supply. Maximum absorption of 1 A corresponding to the sum of all the terminals (+/- 24V).
Terminals J9 (black)	Description
+24V/ OP-I	N.O. opening contact side A (internal side of automation view).
+24V / -24V	24 Vdc output for external accessories supply. Maximum absorption of 1 A corresponding to the sum of all the terminals (+/- 24V).
Terminals J17 (green)	Description
S	Rotary selector signal 31SR0011 / 31SR0012
+24V / -24V	Rotary selector power supply. Maximum absorption of 1 A corresponding to the sum of all the terminals (+/- 24V).


Terminals J4 (grey)	Description
I3	Input terminal for general use. Using the ADV menu > SI3, you can associate the I3 terminal with a specific function.
IO2	Input/output terminal for general use. Using the ADV menu > SIO2, you can associate the IO2 terminal with a specific function.
IO1	Input/output terminal for general use. Using the ADV menu > SIO1, you can associate the IO1 terminal with a specific function.
+24V / -24V	24 Vdc output for external accessories supply. Maximum absorption of 1 A corresponding to the sum of all the terminals (+/- 24V).
Terminals J2 (grey)	Description
LK	Output for activating the electric lock (the functions can be set using the advanced parameters menu)
Terminals	Description
ENC	Rapid connector for angular sensor connection (Encoder)
Terminals J1 (green)	Description
MOT	Connector for motor connection
Connector	Description
USB	USB port. Enables saving and loading of the control unit configuration, saving alarms and carrying out any SW update.

10.4 ELECTRICAL CONNECTIONS OF THE FUNCTIONS SELECTOR 31SR0011 - 31SR0012

Connect the terminals (+24V, -24V, S) on the functions selector, using the cable not supplied by us, for terminals (+24V, -24V, S) of the electronic control.
PLEASE NOTE: For lengths over 10 metres, use a cable with 2 braided pairs.

Symbol	Description	
	DOOR OPEN The door is open and remains open.	
	With two synchronised swing doors, only the master door opens	
	TWO-DIRECTIONAL TOTAL OPENING Allows two-directional door opening.	
	ONE-DIRECTIONAL TOTAL OPENING Allows one-directional operation from the internal/external side of the door.	
	NIGHT CLOSURE The door closes and remains locked (if a lock is present), disabling the radar.	

10.5 OPENING AND SAFETY SENSOR ELECTRICAL CONNECTIONS



Terminals	(A) (B) External / Internal Opening Sensor		
	31RM0002. (ArtMotion 2)	31RM0003. (Merkur 2)	31RM0004. (Eagle Artek)
OP-E / OP-I	Yellow	4 - Blue	Yellow
+24	Brown+green	1-White + 3-Brown	Red+Yellow
-24	White	2 - Black	Black

Terminals	(C) Safety sensor			Notes
	31RS0001/2 (Uniscan)	31RS0006/7 (FlatScan SW) Dip1=OFF	31RS0008. (FlatScan SW) Dip1=OFF	
TS	6	Red	Red	
CS	5	Grey	Grey	Remove the jumper
+24 V	2 + 3	Green+Pink	Green+Pink	
-24 V	1	Brown+Blue	Brown+Blue	
-	-	-	Master-slave cable	Sensors connected via bus

Terminals	(D) Safety sensor			Notes
	31RS0001/2 (Uniscan)	31RS0006/7 (FlatScan SW) Dip1=OFF	31RS0008. (FlatScan SW) Dip1=OFF	
TS	6	Red		
OS	5	White	White	Remove the jumper
+24 V	2 + 3	Green+Yellow	Yellow	
-24 V	1	Brown+Blue		
-	-	-	Master-slave cable	Sensors connected via bus


For further information, refer to the installation manual of the sensor.

11 Low Energy Adjustment


For Low Energy settings, execute the following operations:

- adjust the PUSH strength ≤ 5 ;
- Adjust the VOP opening speed to open the door (from 0° TO 80°) In the times indicated in the table;
- Adjust the VCL closure speed to close the door (from 90° TO 10°) In the times indicated in the table;

APERTURA / OPENING



CHIUSURA / CLOSING



The table shows the minimum open/close time (in seconds)

Door width	Weight of door				
	50 kg	60 Kg	70 Kg	80 Kg	90 Kg
0.75 m	3.0 s	3.0 s	3.0 s	3.0 s	3.5 s
0.85 m	3.0 s	3.0 s	3.5 s	3.5 s	4.0 s
1.00 m	3.5 s	3.5 s	4.0 s	4.0 s	4.5 s
1.20 m	4.0 s	4.5 s	4.5 s	5.0 s	5.5 s

The CP.ARIA central menu is equipped with 5 buttons and 4 alphanumerical displays to set all the necessary adjustments. Operation of the 4 keys is indicated in the table

Buttons	Description
PP	OPEN button. Carries out an OPEN command equivalent to a priority open.
ENTER	Selection button, each time it is pressed you enter the selected parameter. Saving button, pressing for 1 second you "SAVE" the selected value.
ESC	Escape button, each time it is pressed you exit the selected parameter or from the menu.
↑	Scroll button, each time it is pressed, you select a menu item or increase the value of the selected item.
↓	Scroll button, each time it is pressed, you select a menu item or reduce the value of the selected item

12.1 MENU LIST

- **BASE** basic parameters
 - **INFO** board information
 - **MEM** memory management
 - **ADV** advanced parameters
 - **SEL** selector
- press Enter to access the BASE MENU
- press ↑ or ↓ to access the next menus

12.2 BASE MENU

ID	Description	Values	Notes
OPEN	Opening direction selection	→ ←	Opening to right Opening to left
VOP	Opening speed	15 - 70	°/s
VCL	Closure speed	15 - 70	°/s
TAC	Automatic closure time	NO 1 - 30	NO = automatic closure disabled [s]
PUSH	Automation thrust force	1 - 10	1 = min, 10 = max
BTMD	Battery operating mode	NO CONT EMER	Battery not considered Continuous operation Opens in emergency
DOOR	Door type	STD SPRN	standard door door with spring (ARIA S)
ARM	Arm type	PUSH PULL	Articulated arm Sliding arm
LEAF	Door weight	MIN MAX	Light door Medium/heavy weight door
RAMP	Acceleration time	100 - 2000	100 = Maximum acceleration [ms]

12.3 INFO MENU

ID	Description	Values	Notes
VER	Fw version	XXXX	XXXX = firmware version
CYCL	Number of executed manoeuvres	0 - 9999	Number of executed manoeuvres in thousands: 1 = 1000 manoeuvres
SERV	Maintenance signalling setting	NO 1 - 9999	NO = signalling disabled Number of manoeuvres (in thousands) after which the maintenance warning on the control unit display is signalled or setting SIO1/SIO2 signal
LOG	Saving the board log	NO/YES *(NOMS)	Insert USB flash drive. Select YES and press ENTER until the word SAVE appears. The log file (text file) will be saved in MYONEDS/SWING/LOG/ *If NOMS appears, the USB flash drive is not detected or absent
WARN	List of the last 10 warnings		The warnings are put in the order of the most recent to the oldest (0.xxx ... 9.yyy)

12.4 MEM MEM

ID	Description	Values	Notes
FSET	Back to factory settings	NO/YES	Select YES and press ENTER, after 2s the writing "FSET" re-appears, confirming the operation. Resetting the default settings causes automatic resetting of the board, which therefore on subsequent movement will execute an acquisition manoeuvre
FW	Fw upgrade on board	Name of upgrade files *(NOMS)	Insert USB flash drive. Select the Firmware version to upgrade from those available. The upgrade files should be inserted in the path MYONEDS/SLIDING/FW/ *If NOMS appears, the USB flash drive is not detected or absent
SIN	Settings loading from USB	NO/YES *(NOMS)	Insert USB flash drive. Select YES and keep ENTER pressed until the writing SAVE appears. *If the word NOMS appears, the USB flash drive is not detected or is absent
SOUT	Settings saving on USB key	NO/YES *(NOMS)	Insert USB flash drive. Select YES and keep ENTER pressed until the writing SAVE appears. *If the word NOMS appears, the USB flash drive is not detected or is absent

12.5 ADV (Advanced) menu

ID	Description	Values	Notes
SCEX	Space for safe bypass during closure	0 10- 50	Safety not bypassed Interval in degrees within which the safety is bypassed (angle measured compared to closure stop)
SOEX	Space for safe bypass during opening	0 10- 50	Safety not bypassed Interval in degrees within which the safety is bypassed (angle measured compared to opening stop)
SSOP	Behaviour on safety activation opening	CLOS	On activation of the opening safety, the door stops, then the automatic closure time expires, also with the safety active
		OPEN	On activation of the opening safety, the door stops, then the safety disables and opening continues. The door remains still for the entire time the safety is active.
ELLK	Electric lock operating mode	NO	Electric lock not present
		LOCK	Standard electric lock, theft-proof
		SAFE	Anti-panic electric lock
LKPW	Electric lock power supply voltage	12	12Vdc.
		24	24Vdc.
TALK	Electric lock activation advance time	0.5s - 5s	Use if the electric lock takes a certain time to disengage and allow door movement.
TRLK	Electric lock activation time	0.5s - 5s	Electric lock power supply time
LKSH	Electric lock coupling thrust in closure	NO	No coupling thrust
		MAX	3 levels of applied thrust
		MED	
PIPP	Leaf open check enabled	NO/YES	YES = Check enabled, on each opening, the open position is checked by pushing on the leaf stop
PUCL	Thrust force with door closed	NO	no force
		MAX	3 levels of applied force
		MED	
		MIN	

HOLD	Maintenance force with door open	NO	No push
		MAX MED MIN	3 maximum strength levels applicable to keep the door in the open measurement
TS	Safety sensors test enabling	NO/YES	YES = Sensors test enabled
PUGO	Push and Go	NO/YES	YES = Manual movement of the door from closed door causes opening
MAN	Manual movement	NO/YES	YES= The door can opened by hand, then closed automatically (ARIA S)
MOT	Motor Configuration Disabled	OC	Windings open - Manual opening with little friction
		SC	Short-circuited motor windings Manual opening of the door with greater resistance
SIO1	Setting input/output IO1	NO	Disabled
		INKE	Interlock exclusion contact
		KOPT	Partial Key Open. Priority partial open command
		WARN	Alarm status signalling
		SERV	Number of manoeuvres reached for maintenance signalling
		SIGN	Signalling Select the type of signal using the SIGN parameter
		BELL	Buzzer activation in input/activation of door
		RSET	Automation reset contact
		EMER	Emergency open contact (NC)
		SAM	Select operating mode from signal level SIO1
		STEP	Step-step opening (open impulse/lose impulse). During opening by steps, automatic closure is disabled.
		KO	Key Open Contact (priority Open command)
		VOPN	Virtual open contact
		KC	Key Close Contact (priority Close command)
SIO2	Setting input/output SIO2	NO	Disabled
		INKE	Interlock exclusion contact
		KOPT	Partial Key Open. Priority partial open command
		WARN	Alarm status signalling
		SERV	Number of manoeuvres reached for maintenance signalling
		SIGN	Signalling Select the type of signal using the SIGN parameter
		BELL	Buzzer activation in input/activation of door
		RSET	Automation reset contact
		EMER	Emergency open contact (NC)
		SAM	Select operating mode from signal level SIO1
		STEP	Step-step opening (open impulse/lose impulse). During opening by steps, automatic closure is disabled.
		KO	Key Open Contact (priority Open command)
		VOPN	Virtual open contact
		KC	Key Close Contact (priority Close command)
SI3	Setting input SI3	Same input functions as SIO1	See SIO1 limited to input functions: RSET, EMER, KO, VOPN, KC, STEP, SAM, INKE, KOPT
SIGN	Signalling Activation of output contact SIO1/SIO2 (SIO1/SIO2 set on SIGN)	CLOS	Closed door warning
		INK	Door closed signal due to interlocking
		LAMP	Flashing/light (door in motion)
		AIR	Air knife
		OPEN	Open door warning

TAKO	Automatic closure time in the event of Key Open (KO) input enabling	NO	Closure time equal to TAC (Automatic closure time)
		1 - 30	Differentiated automatic closure time [s]
SYNC	Doors synchronised. Synchronisation of up to 2 automation units via the bus connection	NO	No synchronisation active
		SLV2.	Unit 2 synchronisation slave
		MST2.	Unit 2 synchronisation master
		SLV1.	Unit 1 synchronisation slave
		MST1.	Unit 1 synchronisation master
SDLY	Overlapped synchronised door delay	NO	No delay
		MIN	Minimum delay
		MED	Medium delay
		MAX	Maximum delay

12.6 SEL (Advanced) menu

ID	Description	Values	Notes
MODE	Operating mode	NO	No mode selected
		1DPA.	Partial unidirectional
		PA	Partial
		1D.	Unidirectional
		CLOS	Door closed
		AUTO	Automatic/day mode
		OPEN	Door open
SECL	Selector safety level	NO/CODE	No protection /code protection.
DLAY	Maintenance time of the one-directional opening mode during night stop	1 sec - 5 min	The night stop procedure (night mode) includes passage using the one-directional filter, held for the time specified in DLAY, to allow exiting but not entrance
SAM1	If in the SIO1/SIO2 menu, the item SAM is selected, you can establish which operating mode to set when the contact (SIO1/SIO2) is HIGH	CLOS	Door closed
		AUTO	Automatic/day mode
		OPEN	Door open
		1DPA.	Partial unidirectional
		PA	Partial
SAM2	If in the SIO1/SIO2 menu, the item SAM is selected, you can establish which operating mode to set when the contact (SIO1/SIO2) is LOW	1D.	Unidirectional
		CLOS	Door closed
		AUTO	Automatic/day mode
		OPEN	Door open
		1DPA.	Partial unidirectional
RPEN	Enable remote programmer mode	PA	Partial
		1D.	Unidirectional
		NO/YES	RPEN set to YES allows you to activate the remote programmer mode, or if set to NO it does not allow you to enable the remote programmer mode.
		CODE	Code management (from keypad or from NFC tags)
		NO	No storage
CODE	Code management (from keypad or from NFC tags)	DPRG	Deletion of the remote programmer mode enabling codes only
		DALL	Complete deletion of the code list
		DELC	Code deletion
		PROG	New code saving for remote programmer mode activation
		OPEN	New priority open command code saving
		SEL	New code saving for selector unlocking (function selector mode)
CIN	Import codes	NO/YES *(NOMS)	It allows you to import the code list stored on a USB flash drive *If the word NOMS appears, the USB flash drive is not detected or is absent
COUT	Export codes	NO/YES *(NOMS)	It allows you to export the code list on a USB flash drive *If the word NOMS appears, the USB flash drive is not detected or is absent
SHOW	Display of possible anomalies and operating information on the display	ALL WARN	Display of active contacts of the terminal boards + warning Warning only
INK	Interlocked doors. Interlocking of two automation units via the bus connection	NO	No active interlock
		EXT	External side automation
		INT	Internal side automation

13.1 ALARMS

Code	Description	Notes
W001	Encoder fault	Encoder faulty The automation blocks
W002	Motor short circuit	A motor short circuit has been detected. The control blocks movement for 1.5s then tries to power the motor again
W003	Motor control error	Error on motor control circuit. The automation blocks
W004	Current reading circuits fault	Reading the motor currents is not correct. The automation blocks
W010	Movement inverted	Movement detected of direction contrary to that set. The automation blocks.
W011	Stroke too long.	During the acquisition phase, a stroke was detected over the maximum permitted. The automation blocks
W012	Stroke too short	During the acquisition phase, a stroke was detected under the minimum permitted. The automation blocks
W013	Beyond stop	During operation, a stroke was detected longer than that acquired. The automation blocks
W014	Motor absent/faulty	Detected in approx. 3s, if the motor was detached or faulty (no current absorption)
W100	User program not correct, Absent	Software upgrade unsuccessful or corrupted. Switch off and back on the board (with the USB pen inserted) to restart the upgrade procedure

13.2 EVENTS

Code	Description	Notes
W126	Internal error	Alarm that groups all the internal test failures of the board
W128	No mains power supply	
W129	No battery	Enabled if an operating mode is set which includes battery presence
W130	Low battery	Insufficient battery voltage detected
W140	OS safety test failed	The door stays open
W142	CS safety test failed	The door stays open
W145	High motor temperature	Manoeuvre speed lowered to safe value [15°/s]
W146	Motor overtemperature	Door stopped until the motor temperature returns to safe values
W148	Lock overcurrent	Anomalous lock power supply current (too high)
W150	Opening obstacle	Obstacle detected during opening manoeuvre. The door stops and closes once the automatic closure time is up
W151	Closure obstacle	Obstacle detected during closure manoeuvre. The door reopens
W152	Door locked in closure	Door cannot start opening manoeuvre. The door does not accept commands for 5s
W153	Door locked in opening	Door cannot start closure manoeuvre. The door does not accept commands for 5s
W160	Communication alarm	Communication interrupted between coupled boards or non-coherent roles in the coupled operating mode (e.g. both automations are selected as INT or EXT in interlocked operation)
W256	Board on	
W257	Start software board	
W320	Maintenance event	Enabled once the automation has executed the specified number of manoeuvres from the maintenance parameter

14.1 INTRODUCTION

Installation description for synchronised and/or interlocked automation modes

14.2 CONNECTION WIRING


The interlock and synchronisation functions use the communication bus identified on the board by the terminal board 'L H +24 -24'.

First of all, the automations that you want to synchronise or interlock must be connected by wiring the 'L H +24' signals

Note: Do not connect the -24V signal between the boards.

14.3 SYNCHRONISATION OF TWO AUTOMATIONS

Once the wiring of the communication bus has been performed correctly, to activate the synchronisation of two automations, connect the opening sensors, for example on the master automation, and connect the safety sensors on both automations as indicated in chapter 10.5; the sensors operate according to the following diagram, and both automations, by bus, synchronize their movement in the event of an opening command or intervention of one of the safety devices.



Finally, you must make the following settings:

- menu ADV > SYNC:

Set an automation on MST1, master automation. In the case of overlapping doors, it is the one that overlaps (blocking the other door)
Set the other automation to SLV1, slave automation. In the case of overlapping doors, it is the one that is blocked by the other leaf

NOTE: it is possible to define a maximum of 2 units of synchronised doors. The doors that make up unit '1' are identified by [MST1, SLV1], while the doors that make up unit '2' are identified by setting [MST2, SLV2].

- If you need to activate a second unit of doors, repeat the ADV/SYNC settings by selecting MST2 and SLV2 on the automations that will form unit '2'

To adjust the delay in the case of overlapping doors:

- menu ADV > SDLY, choose:

NO if there is no overlapping
MIN, MED or MAX based on the delay you want to have between the two doors

14.3.1 Synchronisation operation

When the system is switched on, at the first opening manoeuvre, the doors will open one at a time, first the master, then the slave. Once the manoeuvring space has been acquired, the movement will be synchronised according to the selected settings.

14.4 INTERLOCKING OF TWO AUTOMATIONS

Once the communication bus has been correctly wired, the following settings must be carried out to activate the interlocking of two automations:

- menu ADV > INK:

It is necessary to distinguish between automation on the internal side and automation on the external side.
Select the INT item to indicate the automation on the internal side and the EXT item to indicate the automation on the external side

It is possible to associate the activation of a SIO1/SIO2 output to the interlock operation, for example to command a light signalling the status of the door:

- menu ADV >SIO1/SIO2:
select the SIGN item
- menu ADV >SIGN:
select the INK item

The IO1/IO2 output will be activated when the door is locked due to the interlock (with this signal, for example, it will be possible to turn on the red light signal to indicate that the passage is temporarily blocked)

It is possible to temporarily disable the interlock function via button/contact:


- menu ADV >SIO1/SIO2/SI3:
select the INKE (Interlock Exclusion) item

Closing the IO1/IO2/I3 output on +24V will disable the interlock function.

14.4.1 Interlock operation

The interlocked automations will open one at a time, waiting until the other automation is closed before opening.

NOTE: It is important to establish the correct direction of travel by indicating the internal and external automation, then correctly setting the internal and external radar as these choices affect the interlock's operating logic.



Starting from the rest state, in which both automations are closed, the first to receive an open command starts the opening manoeuvre. The other automation, on the other hand, goes into the 'locked' state where it does not accept any opening commands from the OP-I OP-E contacts. It is however possible to open (for safety reasons etc) using the KO priority open command. (to be configured on IO1, IO2 or I3)

Once the opening door has reached the open position, its radar signals and safety lock outside the interlocking compartment are disabled, this is in order to facilitate prompt closing.

The signals will remain disabled for the entire closing manoeuvre and for the subsequent opening/closing of the other door.

Once the other door has been opened/closed all the signals are re-enabled.

15.1 Preliminary checks

At the end of the installation activities, manually move the doors and check movement is regular and friction free.

Check the structure is solid and correctly fasten all the screws.

Check the electrical connections are all correct.

15.2 Before connecting any safety devices, leave the jumpers on the safety terminals of the electronic control (TS-CS, TS-OS).

PLEASE NOTE: The first opening and closure manoeuvre is carried out with low speed to enable automatic detection of the stop measurements.

15.3 To ensure the electronic control has the factory settings, restore the values using the menu:

MEM > FSET > YES (confirm by pressing ENTER for 1 second).

15.4 Execute menu adjustments as indicated in chapter 12. Use the PP key to give the opening commands and check the door is working properly.

PLEASE NOTE: The automation automatically recognises possible obstacles during the closure (movement inversion) and opening manoeuvre (movement stoppage).

15.5 Connect the command and safety devices one at a time to protect the door closure manoeuvre, as indicated in chapter 10.5 and checking its correct operation.

PLEASE NOTE: Check the passage compartment is correctly protected from safety sensors, in compliance with the provisions of the European standard EN16005 (Annex C).

15.6 Connect the safety devices one at a time to protect the door opening manoeuvre, as indicated in chapter 10.5, and check its correct operation.

PLEASE NOTE: In the event of distances between the door and the fixed parts, comply with the European standard EN16005 (chapter 4.6.2.1.a), the safety sensors in opening are not necessary ($X \leq 100$ and $Y \geq 200$).

15.7 Connect the function selector as indicated in chapter 10.4.

15.8 When start-up is complete, deliver the use instructions to the manager of the automatic door, including the warnings and information necessary to maintain safety and functionality of the automatic door.

PLEASE NOTE: The manufacturer of the automatic swing door must add its identification label of the system.

Problem	Possible cause	Intervention
The automation does not open or close.	No mains power supply (display off).	Check the mains power supply is present.
	Accessories outside the short circuit.	Disconnect all the accessories from the terminals -24V/+24V and reconnect them one at a time (check the presence of 24V voltage).
	The door is locked with latches or locks.	Check the doors move freely.
The automation does not execute the functions set.	Functions selector with wrong setting.	Check and correct the functions selector settings.
	Command or safety devices are always enabled.	Disconnect the devices from the terminal boards and check the door is working.
Movement of the doors is not linear or movement is inverted for no reason.	Automation did not correctly detect the stop measurements.	Reset by switching the automation off and back on.
The automation opens but does not close.	The safety devices test causes anomalies.	Bridge one contact at a time TS/OS TS/CS.
	The opening devices are enabled.	Check the opening sensors are not subject to vibrations, do not make false detections or the presence of objects in motion in the action range.
	Automatic closure is not working.	Check the settings of the functions selector.
The safety devices do not intervene.	Wrong connections between the safety devices and electronic control.	Check the safety contacts of the devices are correctly connected to the terminal boards and the relevant jumpers were removed.
The automation opens by itself.	The opening and safety devices are unstable or detect bodies in motion.	Check the opening sensors are not subject to vibrations, do not make false detections or the presence of bodies in motion in the action range.
	Automation has detected an anomaly.	Check the electrical mains is present. Check the battery connection and its efficiency.
The locking device does not lock or does not unlock the doors.	Wrong connection of the locking device on electronic control.	Check correct connection of the cable colours on the locking device.
	The lock coupling brackets, fastened on the carriages, do not release from the locking device.	Check adjustment of the position of the lock coupling brackets.

To guarantee correct operation and safe use of the automatic door, as outlined in the European standard EN16005, the owner must have professionally competent staff carry out routine maintenance.

Except for routine cleaning activities of the fixture and possibly the sliding guides on the floor, the competence of the owner, all the maintenance and repair activities must be carried out by professionally competent staff.

The following table lists the activities relating to ordinary maintenance, and the intervention frequency referring to the automatic swing door with operation in standard conditions. In the event of more burdensome conditions, or in the event of sporadic use of the automatic swing door, the frequency of the maintenance intervention can be coherently adequate.

Activity	Frequency
Disconnect the power supply and open the automation and execute the following checks and adjustments. - Check correct fastening of all the screws on the components inside the automation. - Check correct voltage of the belt.	Every 6 months or every 500,000 manoeuvres.
Connect the mains power supply and execute the following checks and adjustments. - Check correct operation of the command and safety devices. - Check the detection area of the safety sensors complies with the provisions of the European standard EN16005. - If present, check the locking device is working correctly. - Check the battery-powered device is working properly (if necessary, proceed to replace the battery).	Every 6 months or every 500,000 manoeuvres. PLEASE NOTE: Check the safety functions of the automation and the safety devices which must be carried out at least once a year.

All maintenance, replacement, repair, upgrading, etc. operations must be written on the maintenance register, as requested by the European standard EN16005, and delivered to the owner of the automatic swing door.

For possible repair or replacement of products, original spare parts must be used.

17.1 DISPOSAL OF PRODUCTS

INFORMATION FOR USERS

"Implementation of Directive 2012/19/EU on waste electrical and electronic equipment (WEEE)"



The crossed bin symbol outlined on the equipment indicates the product at the end of its useful life must be collected separately from other waste. The user should therefore give the equipment with essential components intact at the end of its useful life to suitable electronic and electro-technical differentiated waste centres, or deliver it to the dealer on purchase of new, equivalent type equipment, in the region of one to one, or 1 to zero for equipment with its longest side under 25cm. Adequate differentiated collection for subsequent sending of the decommissioned equipment for recycling, processing and compatible environmental disposal contributes to avoiding negative effects on the environment and health and promotes recycling of the components of the equipment.

MAINTENANCE LOG BOOK

FOR AUTOMATIC PEDESTRIAN DOORS IN COMPLIANCE WITH THE MACHINERY DIRECTIVE 2006/42/EC AND THE EUROPEAN STANDARD EN 16005

This maintenance log book contains technical data and records of installation, maintenance, repair and modification activities, and must be made available for inspection by authorised bodies.

TECHNICAL DATA OF THE AUTOMATIC DOOR AND INSTALLATION

Manufacturer/Installer:	_____	Name, address, contact person
Customer/Owner:	_____	Name, address, contact person
Order number:	_____	Number and date of order
Name and description:	_____	Type of door
Dimensions and weight:	_____	Dimensions of the passage compartment, dimensions and weight of the doors
Serial number:	_____	Unambiguous identification number of the door
Location:	_____	Installation address

LIST OF COMPONENTS INSTALLED

The technical features and performance of the components listed below are documented in the relevant installation manuals and/or on the label attached to the component.

Automation:	_____	Model, type, serial number
Motor:	_____	Model, type, serial number
Electronic control:	_____	Model, type, serial number
Safety devices:	_____	Model, type, serial number
Control devices:	_____	Model, type, serial number
Miscellaneous devices:	_____	Model, type, serial number
Other:	_____	Model, type, serial number

TEST REPORT				
Tick the box corresponding to the operation carried out: C = Conforming, NC = Non-conforming, NA = Not applicable.				
Phase	Description	C	NC	NA
1	Check the existing structure and automation fixing			
2	Check doors correctly fixed to the automation carriages and adjustment			
3	Check the carriages cannot exit the sliding guide			
4	Check the belt voltage			
5	Check the mechanical limit switches, and tightness of all the screws			
6	Check the floor guide			
7	Check the doorway complies with contractual data			
8	Check the distance between the leaf and the floor			
9	Check the safety distance on opening			
10	Manually check the leaves slide freely without friction			
11	Check the electrical connections of the devices installed			
12	Check the detection area of the opening and safety sensors			
13	Check the additional opening commands (buttons, contacts with key, etc.)			
14	Check the function selector			
15	Check operation with the battery			
16	Check the manual locking and unlocking device function			
17	Check the opening and closing speed			
18	Delivered to the owner, the Declaration of Conformity			
19	Delivered to the owner, the Use and Maintenance Manual			
20	Delivered to the owner, the Maintenance Register			
Date _____		Technician's signature _____		Owner's signature _____

DESCRIPTION OF OPERATION		
Tick the box corresponding to the operation carried out. Describe any residual risks and/or foreseeable misuse.		
<input type="checkbox"/> Installation		
<input type="checkbox"/> Start-up		
<input type="checkbox"/> Adjustment		
<input type="checkbox"/> Maintenance		
<input type="checkbox"/> Repair		
<input type="checkbox"/> Modification		
Date _____	Technician's signature _____	Owner's signature _____

DESCRIPTION OF OPERATION		
Tick the box corresponding to the operation carried out. Describe any residual risks and/or foreseeable misuse.		
<input type="checkbox"/> Installation		
<input type="checkbox"/> Start-up		
<input type="checkbox"/> Adjustment		
<input type="checkbox"/> Maintenance		
<input type="checkbox"/> Repair		
<input type="checkbox"/> Modification		
Date _____	Technician's signature _____	Owner's signature _____

DESCRIPTION OF OPERATION		
Tick the box corresponding to the operation carried out. Describe any residual risks and/or foreseeable misuse.		
<input type="checkbox"/> Installation		
<input type="checkbox"/> Start-up		
<input type="checkbox"/> Adjustment		
<input type="checkbox"/> Maintenance		
<input type="checkbox"/> Repair		
<input type="checkbox"/> Modification		
Date _____	Technician's signature _____	Owner's signature _____

DESCRIPTION OF OPERATION		
Tick the box corresponding to the operation carried out. Describe any residual risks and/or foreseeable misuse.		
<input type="checkbox"/> Installation		
<input type="checkbox"/> Start-up		
<input type="checkbox"/> Adjustment		
<input type="checkbox"/> Maintenance		
<input type="checkbox"/> Repair		
<input type="checkbox"/> Modification		
Date _____	Technician's signature _____	Owner's signature _____

DESCRIPTION OF OPERATION		
Tick the box corresponding to the operation carried out. Describe any residual risks and/or foreseeable misuse.		
<input type="checkbox"/> Installation		
<input type="checkbox"/> Start-up		
<input type="checkbox"/> Adjustment		
<input type="checkbox"/> Maintenance		
<input type="checkbox"/> Repair		
<input type="checkbox"/> Modification		
Date _____	Technician's signature _____	Owner's signature _____

DESCRIPTION OF OPERATION		
Tick the box corresponding to the operation carried out. Describe any residual risks and/or foreseeable misuse.		
<input type="checkbox"/> Installation		
<input type="checkbox"/> Start-up		
<input type="checkbox"/> Adjustment		
<input type="checkbox"/> Maintenance		
<input type="checkbox"/> Repair		
<input type="checkbox"/> Modification		
Date _____	Technician's signature _____	Owner's signature _____

DECLARATION OF INCORPORATION

Directive 2006/42/EC, Annex II-B



Myone S.r.l.

Via Abbate Tommaso, 52 - 30020 Quarto d'Altino (VE) - ITALY

Hereby declares that:

The automation product for pedestrian sliding doors type:

ARIA, ARIA S

Has been built to be incorporated into a machine or to be assembled with other machinery or components to constitute a machine in accordance with Directive 2006/42/EC.

The manufacturer of the power operated pedestrian door must declare its conformity in accordance with Directive 2006/42/EC (Annex II-A), before putting the machine into service.

It complies with the applicable essential safety requirements set out in Annex I, *chapter 1 of Directive 2006/42/EC*.

It complies with the *Electromagnetic Compatibility Directive 2014/30/EU*.

It complies with the following harmonised standards:

EN 16005 Power operated pedestrian doorsets - Safety in use - Requirements and test methods (chapters: 4.2, 4.3.1, 4.3.2, 4.3.3, 4.4.1, 4.4.4, 4.4.5, 4.6.1, 4.6.3, 4.6.4, 4.6.7, 4.6.8, 4.7.2.4, 5.1, 5.2, 5.3, 5.4, 5.5.3, 5.6, 5.8.1, 5.8.2, 5.8.3, 5.10)

EN 60335-2-103 Household and similar electrical appliances - Safety. Part 2:

Particular requirements for drives for gates, doors and windows

The technical documentation complies with Annex VII-B of Directive 2006/42/EC

The technical documentation is managed by:

Daniele Vanin

with registered office in Via Abbate Tommaso, 52 - 30020 Quarto d'Altino (VE) - ITALY

A copy of the technical documentation shall be provided to the competent national authorities following a duly motivated request.

Place and date: Daniele Vanin

Quarto d'Altino, 2022-05-16

General Manager

Daniele Vanin
General Manager

GENERAL SAFETY WARNINGS

AUTOMATION FOR SWING DOORS

These warnings are an integral and essential part of the product and must be delivered to the user.

Carefully read them as they provide important instructions on safety of installation, use and maintenance.

You must keep these instructions and give them to anyone sub-entering use of the system.

This product should only be intended for the use for which it was expressly designed.

Any other use should be considered misuse and therefore hazardous.

The manufacturer cannot be considered responsible for any damage caused by improper, wrong or unreasonable use.

This product is not intended for use by people (including children) whose physical, sensory or mental capacities are reduced, or with no experience or know-how, unless they can benefit from the intermediation of a person responsible for their safety, supervision or instructions regarding use of the device.

Avoid working near hinges or mechanical units in motion.

Do not enter the action range of the automated door while it is in motion.

Do not oppose motion of the automated door since it can cause hazardous situations.


Do not allow children to play or stay within the action range of the automated door.

Keep remote controls and/or any other command devices out of reach of children, to avoid the automated door being involuntarily activated.

If the event of a fault or poor operation of the product, disconnect the power supply switch, abstaining from any attempt to repair it or direct intervention and only contact qualified staff. Non-compliance with the above can create dangerous situations.

Any intervention for cleaning, maintenance or repair must be carried out by qualified staff. To guarantee the efficiency of the system and its correct operation, it is indispensable to comply with the manufacturer's instructions, having qualified staff carry out periodic maintenance of the automated door. In particular, you are advised to carry out periodic testing to ensure the safety devices are all working properly. Installation, maintenance and repair operations must be documented.

FUNCTIONS SELECTOR



Symbol	Description
	DOOR OPEN The door is open and remains open.
	With two synchronised swing doors, only the master door opens
	TWO-DIRECTIONAL TOTAL OPENING Allows two-directional door opening.
	ONE-DIRECTIONAL TOTAL OPENING Allows one-directional operation from the internal/external side of the door.
	NIGHT CLOSURE The door closes and remains locked (if a lock is present), disabling the radar.



This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

